Glass Applications

Preparation Guide



It is best to prepare the glass surface by spraying a glass cleaner onto the surface.

If necessary you may need to clean the glass surface with fine steel wool. This will ensure any topical contaminants are removed from the glass surface.

Follow this step with a final spray of Isopropyl Alcohol & wipe dry with a clean lint free cloth or towel.



Glass may be coated with a finish like silicon, that makes long-term adhesion difficult to achieve. Some are topped with a tint or protective

film that makes removing the graphic without damaging the tint nearly impossible.

We recommend applying a sample piece of the vinyl or film in a inconspicuous area for testing.





Check for tinting/protective film prior to installation

☑ Checklist

- ☐ Has the glass been thoroughly cleaned?
- ☐ Have you checked for film or coating?
- ☐ Have you completed an adhesion test?